

Razor Crazy Cart

Problem	Possible Cause	Solution
Product does not run	-Undercharged Battery -Charger is not working	-Charge the battery. A new battery should have been charged for at least 12 hours before using the product for the first time and up to 12 hours after each subsequent use. -Check all connectors. Make sure the charger connector is tightly plugged into the charging port and that the charger is plugged into a functioning wall outlet. -Contact Recreation Ltd to get a replacement charger.
Product was running but suddenly stopped	-Loose wires or connectors	-Check all wires and connectors to make sure they are tight
Short run time	-Undercharged battery -Battery is old and will not accept a full charge	-Charge the battery. A new battery should have been charged for at least 12 hours before using the product for the first time and up to 12 hours after each subsequent use. -Replace only with a Razor Replacement Battery.
Product runs sluggishly	-Riding conditions are too stressful -Product is overloaded	-Use only on solid flat, clean and dry surfaces such as pavement or level ground -Make sure you do not overload the product by allowing more than one rider at one time, exceeding the maximum weight limit, going up too steep a hill or towing objects behind the product.
Sometimes the product doesn't run, but other times it does	-Loose wires or connectors - Motor or electrical switch damage	-Check all wires connectors to make sure they are tight -Contact your local Razor authorised service centre for diagnosis and repair. Contact Recreation Ltd.
Charger gets warm during use	Normal response to charger use.	-No action required. This is normal for some chargers and is no cause for concern. If your charger does not get warm during use, it does not mean that it is not working properly.
Product makes loud noises or grinding sounds	Chain is too dry	Apply a lubricant such as 3 in 1™ or Tri-Flow™ to the chain.

